

# J&J Service Instructions

## Electric Bumper Boat Kartrol Install



- Kartrol receiver



- Attach kartrol receiver to mount plate. Mount holes will have to be drill. A 1/8th drill bit works well.
- Using stainless hardware to attach receiver box is preferable.
- Rivet mount plate to front side of motor mount. Holes are already pre-drilled.



CH1-motor

connect:

blue wire-yellow load wire of motor switch

brown wire- to relay where yellow load wire was connected

green wire is not used

CH2-squirt

connect:

white wire-yellow load wire of squirt switch

orange wire-to fuse where yellow load wire was connected

yellow wire is not used