

SERVICE BULLETIN

February 21, 2000

Proper tube for Bigfoot tires

When ordering tubes for your Bigfoot tires be sure that you are ordering the correct tube for optimum performance.

The proper tube to use is part number: **00780 3.40/3.00x5**

As seen below the Bigfoot on the left compared with the Powermaster on the right has a smaller inside diameter. That is due to the increased amount of Rubber to the road without increasing the outside diameter of the tire.

When a 4.10x3.50x5 tube is used in a Bigfoot tire it will not inflate properly causing it to fold which can weaken the tube and even cause premature failure. The **00780 3.40/3.00x5** tube can be used in any of the 5" tires we carry.



If you have any questions please call service at
(800) 854-3140 or (503) 304-8899.

